




Closed Caption System

When you tune a Closed Caption Broadcast, you may watch dramas, movies and news etc. with captions containing the dialogues and the contents of news.



Remote Control

Make sure ...

- your TV/VCR is turned on (see pages 6–7).
- to make each entry within 60 seconds, otherwise the TV/VCR will exit the Clock Set mode and you will have to start over.

Select the Menu Screen

1

Press the MENU button.

TV/VCR Screen

TO SELECT PUSH NO. SHOWN
 1 PROGRAM
 2 TV SET UP
 3 VCR SET UP
 4 TUNER SET UP
 5 CLOCK SET
 6 DAYLIGHT SAV. TIME
 7 CLOSED CAPTION SET UP

TO END PUSH MENU

Select the Closed Caption Mode

2

Press the NUMBER 7 button to select "CLOSED CAPTION SET UP."

TO SELECT PUSH NO. SHOWN
 1 CAPTION MODE
 2 CAPTION CC1
 3 CAPTION CC2
 4 TEXT CC1
 5 TEXT CC2

TO END PUSH MENU

Select the Broadcast

3

First, press the NUMBER 1 button to select "CLOSED CAPTION MODE."

Next, press NUMBER 2, 3, 4 or 5 to select your desired broadcast.

"ON" appears beside "CAPTION MODE" and the selected type.

TO SELECT PUSH NO. SHOWN
 1 CAPTION MODE ON
 2 CAPTION CC1 ON
 3 CAPTION CC2
 4 TEXT CC1
 5 TEXT CC2


TO END PUSH MENU

Watch the Caption Broadcast

4

Press the Menu button.

The selected caption broadcast appears on the TV screen.



Closed Captioning (CC) allows you to read the voice content of television programs on the TV screen. Designed to help the hearing impaired, this feature uses on-screen "text boxes" to show dialogue and conversations while the TV program is in progress.

STANDARD (CC1):

Dialogue (and descriptions) for the action on the captioned TV program shows on-screen. (See "NOTE" at bottom of page.)

SECOND LANGUAGE (CC2):

Foreign language translation of dialogue (and descriptions) for the action on the captioned TV program shows on-screen.

FULL SCREEN TEXT 1 or 2:

Often used for channel guide, schedules, or bulletin board information for CC programs.

Remember Broadcast stations will often use spelling abbreviations, symbols, dropouts and other grammatical shortcuts in order to keep pace with the on-screen action. These type factors vary upon the source of the captioned text material and do not indicate a need for service on the part of the TV.

WORLD WEATHER			
NYL	CLOUD	5°C	23:00
LOS	RAIN	8°C	20:00
LONDON	CLOUD	7°C	4:00
MOSCOW	SNOW	-8°C	7:00
CAIRO	FINE	27°C	8:00
TOKYO	FINE	15°C	18:00
SYDNEY	RAIN	23°C	14:00
RIO	CLOUD	25°C	1:00



Not all TV programs and product commercials are made for broadcast with Closed Caption (CC) information included. Neither are all Closed Caption modes (SECOND LANGUAGE, FULL SCREEN TEXT1, etc.) necessarily being used by a broadcast station during the transmission of a closed caption programs. Refer to your area's TV program listings for the stations and times of Closed



...to the next page and learn how to set the Sleep Timer.